

Watch with vibrating alarm



DAILY USE

- Press the Time/Alarm button once to show the time.
- Press the Time/Alarm button twice to check the charging of the battery (from 0 to 100 percent)
- The vibration can be stopped immediately by pressing a button, or it will stop automatically in 60sec.

CHARGE THE WATCH

Remove the watch from the rubber case and connect the watch USB port to your power bank (5V) or laptop. With the USB cable attached, a blue light will flash indicating it's charging. When the watch is 100% fully charged the blue indicator light will be always on. A fully charged watch lasts 6-15 days.

SET THE TIME

- When the screen is black, press the Timer button to make sure the timer is off. Cdn should be displayed. If Cdn is not displayed, and the countdown time is displayed, hold down the button below for 5 seconds. "Off" will be displayed indicating that the timer is off.
- When the screen is black, press the Time/Alarm top button to see the current time setting.
- When the time is showing, hold down the Time/Alarm button until the hours are flashing.
- Press the Time/Alarm button to increase the hours and the Timer button to decrease the hours.
- When the hours are correct, hold down the Time/Alarm button until the minutes are flashing.
- Press the Time/Alarm button to increase the minutes and the Timer button to decrease the minutes. When the correct time is shown, wait 5 seconds until the screen turns off. The time is now set.

SET THE ALARMS (UPTO 15 ALARMS)

- When the screen is black, press the Timer button to make sure the timer is off. The text Cdn should be displayed. If Cdn is not displayed, and the countdown time is displayed, hold down the Timer button for 5 seconds. "Off" will be displayed indicating that the timer is off.
- When the screen is black, press the Time/Alarm top button 4 times to see the time setting of the first alarm (A1).
- With the time showing, hold down the Time/Alarm button until the hours are flashing.
- Press the Time/Alarm button to increase the hours and the Timer button to decrease the hours.
- When the hours are correct, hold down the Time/Alarm button until the minutes are flashing.
- Press the Time/Alarm button to increase the minutes and Timer button to decrease the minutes.
- When the correct time is shown, wait 5 seconds until the screen turns off. The time of the first alarm is now set.
- To activate or deactivate the first alarm, when the screen is black, press the Time/Alarm button 5 times. Before the screen turns off, hold down the Time/Alarm button for 3 seconds to toggle between alarm on (A1 ON) or off (A1 OFF). When the correct setting is shown, wait 5 seconds until the screen turns off and the activation/deactivation of the alarm is saved.
- The time setting of the second alarm (out of 15 alarms) is reached after pressing the Time/Alarm button 6 times, third alarm after 8 times, forth after 10 times and so on. The time of the different alarms are shown before the indication if the alarm is on or off.
- The activation/deactivation of the second alarm is reached after pressing the top button 7 times, third after 9 times, forth after 11 times and so on.

SET THE TIMER

- When the screen is black, press the Timer button twice to set the timer. Cdn will be displayed after the first press and at the second press the number of minutes is shown that the timer will be set to. Keep pressing the Timer button until the desired number of minutes (from 1 to 180 minutes).
- Hold down the Timer button for 3 seconds and "On" is displayed indicating that the timer is activated.
- To see the remaining time on an activated timer, simply press the Timer button when the screen is black.
- To turn off the timer, first press the Timer button when the screen is black and the countdown time is displayed. Then, hold down the Timer button for 5 seconds. "Off" is displayed indicating that the timer is off.

TECHNICAL SPECIFICATIONS

Power source DC 5V, Charging Input micro USB, Outside temperature 0 to 45 degrees C.

ENVIRONMENT

At the end of the lifetime, dispose of each part of the product separately at the appropriate recycle station.

WARRANTY

The Pjama watch has a two-year warranty from the buyer's date of the alarm. You must be the original buyer and show evidence of your purchase. This warranty does not apply if caused by an accident or similar incident or injury, water damage, negligence, abnormal use or failure to comply with the instructions in this manual.

CAUTION

- Danger of explosion if the battery is incorrectly replaced. Replace only with the equivalent battery.
- The battery should not be exposed to excessive heat, fire or the alike.
- The watch is resistant to water such as taking a shower or washing your hands. It is not suited for immersion or swimming.
- Make sure to close the silicon cap over the USB port after charging.
- Do not repair the device yourself, but contact an authorized specialist.

Pjama AB, Box 5, 274 21 Skurup, Sweden