


PJAMA SÄNGVÄTNINGSLARM



KNAPPIAGRAM LARMENHET KNAPPFUNKTIONER

🔊	Volym
⌚	På/Av
🎵	Val av ljud

BRUKSANVISNING

För bästa resultat: Barnet ska vara motiverat och vilja bli torr. Föräldern behöver hjälpa barnet att vakna, framförallt i början av behandlingen.

OBS: Ladda larmenheten innan användning. Använd medföljande USB-kabel. Sensorn behöver inte laddas och är redan parad med larmenheten.

Laddning via:	Tid - full laddning
Dator	4-6 timmar
Nätadapter 5V 1.0A	3 timmar

Under laddning blinkar en röd LED lampa. När laddning är klar kommer den röda LED-lampan att lysa konstant.

1. Sätt på larmet genom att trycka på ⌂knappen. En blå LED-lampa börjar blinka vid sidan om ⌂knappen och du hör ett bip-ljud (fem gånger) som indikerar att larmet är aktiverat.

2. Tryck på 🎵knappen och välj ett av de sju olika larmljuren.

Det senaste spelade ljuset blir det som kommer att larma.

3. Reglera volymen med 🔊knappen till önskad volym.

4. Placer larmenheten på önskad plats i rummet. För att testa larmenheten, kortslut kontakterna på sensorn genom att använda ett metalobjekt. Räckvidd på larm ca 10m.


5. Sätt fast sensorn på knapparna som finns i fickan på insidan av Pjama byxorna. Se till att den sitter fast ordentligt. Larmet är nu klart att användas.

6. Tryck på ⌂knappen för att stänga av larmet.

7. Knäpp loss sensorn från Pjama byxorna när larmet inte ska användas eller när Pjama byxorna ska tvättas. Torka av sensorn om den blivit blöt.

Ta kontroll över ditt barns sängvätning med Pjama appen! Lagra enkelt torra/våta nächter, använd telefonen som larm och få instruktioner med tips. Finns för både iOS och Android.

För mer information se [www.pjama.se/
produtt-manualer](http://www.pjama.se/produtt-manualer)



Kortsluta kontakterna på sensorn med hjälp av ett metalobjekt till exempel en saks.

GARANTI


Pjama sängvätningslarm har ett års garanti från inköparens datum av larmet. Du ska vara den ursprungliga köparen och kan uppvisa underlag på ditt köp. Denna garanti gäller inte vid ett fel orsakat av en olycka eller liknande incident eller skada, vattenskada, vårdslöshet, onormal användning eller underlätenhet att följa anvisningarna i denna bruksanvisning.

BEMÆRK: Oplad alarmenheten inden brug. Brug det medfølgende USB-kabel. Sensoren skal ikke lades op og er allerede parret med alarmenheten.

6. Tryk på ⌂ knappen for at slukke alarmen.

7. Tag sensoren af Pjama-bukserne, når alarmen ikke er i brug, eller hvis Pjama-bukserne skal vaskes. Tør sensoren af, hvis den er våd.

PJAMA SENGEVÆDNINGSLARM



KNAPDIAGRAM OG FUNKTIONER ALARMENHED

🔊	Volume
⌚	Tænd/sluk
🎵	Valg af lyd

INSTRUKTION

For bedste resultat: Barnet skal være motiveret og ønske at blive tør. Forældre er nødt til at hjælpe barnet med at vågne, især i begyndelsen af behandlingen.

BEMÆRK: Oplad alarmenheten inden brug. Brug det medfølgende USB-kabel. Sensoren skal ikke lades op og er allerede parret med alarmenheten.

6. Tryk på ⌂ knappen for at slukke alarmen.

7. Tag sensoren af Pjama-bukserne, når alarmen ikke er i brug, eller hvis Pjama-bukserne skal vaskes. Tør sensoren af, hvis den er våd.


GARANTI

Pjama sengevædningsalarmen har en etårs garanti fra alarmens købsdato. Du skal være den oprindelige køber og have dokumentation for dit køb. Garantien gælder ikke, hvis forårsaget af et uheld eller lignende hændelse eller tilskadekomst, vandskade, forsommelse, unormal brug eller manglende overholdelse af instruktionerne i denne manual.

ADVARSEL

- Pjama Sengevædningsalarm er tiltænkt som en inkontinens-alarm til børn fem år eller ældre, eller som anbefalet af en læge.
- Sørg for at sikre, at ingen dele af Pjama Sengevædningsalarmen bliver puttet i munden under nogen omstændigheder. Det ville kunne forårsage kvæfning eller anden tilskadekomst.
- Pjama Sengevædningsalarmen er medicinsk udstyr og skal behandles som sådan med forsigtighed.
- Hold ikke en alarmerende højtaler tættere end 4 tommer (10 cm) fra øret. Det vil kunne forårsage skader på øret.
- Oplad ikke højtalerenheten i løbet af natten, eller hvis du ikke er hjemme.
- Afbryd sensoren fra bukserne, når den ikke er i brug, for at forlænge batterilevetiden.

PJAMA BEDWETTING ALARM



BUTTON DIAGRAM AND FEATURES ALARM UNIT

	Volume
	On/Off
	Select sound

INSTRUCTION

For best results: The child should be motivated and want to get dry. The parent needs to help the child to wake up, especially at the beginning of the treatment.

NOTE: Charge the alarm unit before use. Use the supplied USB cable. The sensor does not need to be charged and is already paired with the alarm unit.

Charging via:	Time - fully charged
Computer	4-6 hours
AC Adapter 5V 1.0A	3 hours

During charging, a red LED light flashes. When charging is complete, the red LED light will light constantly.

1. Turn on the alarm by pressing the button. An LED light flashes to the left of the button and you will hear a beep (five times) indicating that the alarm is activated.

2. Press the button and select one of the seven different alarm sounds. The last played sound will be the sound alarming.

3. Adjust the volume with the button.


4. Place the alarm unit in the desired location in the room. To test the alarm unit, short the contacts on the sensor using a metal object (see picture below). Range of alarm about 10m.

5. Attach the sensor to the buttons located in the pocket on the inside of the Pjama pants. Make sure it is securely fastened. The alarm is now ready to use.

6. Press the button to turn off the alarm.

7. Unplug the sensor from Pjama pants when the alarm is not being used or when the Pjama pants are to be washed. Wipe of the sensor if it is wet.

For more information, see www.pjamastore.com/product-manuals



Short-circuit the contacts on the sensor using a metal object such as scissors.

WARRANTY

The Pjama bedwetting alarm has a one-year warranty from the buyer's date of the alarm. You must be the original buyer and show evidence of your purchase. This warranty does not apply if caused by an accident or similar incident or injury, water damage, negligence, abnormal use or failure to comply with the instructions in this manual.

CAUTION

- Children age five and older, or as recommended by a physician.
- Pjama Bedwetting Alarm is intended for use as an enuresis alarm. Make sure that no parts of the Pjama Bedwetting Alarm are put in the mouth for any reason. This could cause choking or other harm.
- The Pjama Bedwetting Alarm is a medical device it should be treated as such, with care.
- Do not hold an alarming speaker within 4 inches (10 cm) of the ear. This could cause damage to the ear.
- Do not charge speaker unit during night or when not home.
- To extend battery life, disconnect sensor from pants when not being used.

FCC WARNING

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note:

This equipment has been tested and found to comply with the limits for Class B digital devices, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

2020-04-20

Pjama AB, Stortorget 13A, 211 22 Malmö, Sweden